






REGULAR BRICKS



STAX



Power STAX

















Light STAX























































1-8














1-10






































1-16














1-18


























1-22









1-24




















30822 TRACTOR 1!









1-28




















Special instructions:

- 1. To replace the CR2032 button cell battery, please see the 4x4 Motion Activated Power STAX Instruction manual.
- 2. As an upgrade, to avoid using batteries, we recommend replacing the button cell Power STAX with the rechargeable 4x4 Mobile Power STAX (Item# S-11503). You can purchase this from your STAX retailer or directly through our webshop at www.lightstax.eu!