






X1



X1




Right Vehicle Light X2

X2


30803 PICKUP TRUCK



























































































30803 PICKUP TRUCK













30803 PICKUP TRUCK


















Special instructions:

1. To replace the CR2032 button cell battery, please see the 4x12 Power Base Instruction manual.