




30805 RACE CAR 1



REGULAR BRICKS




STICKER



STAX












Left Vehicle Light Right Vehic X2 X2






1-2








30805 RACE CAR 3






































































RC30805





| Special instructions: | |
|---|---------|
| I 1. To replace the CR2032 button cell battery, please see the 4x12 Power Base Instruction r | manual. |
| | |
| | |
| | |
| | |
| I. | |
| | |
| | |
| I | |
| | |
| | |
| I | |
| | |
| | |

30805 RACE CAR 10